

Batak Racers v1.0

SOFTWARE GUIDE

Before proceeding, make sure that you have installed the 'USB to Serial Cable' drivers. Details of this installation procedure are explained in the **BATAK Jockeys** manual.

Please note, **Batak Racers** requires the **player consoles** and **master control box** to be plugged in **before** proceeding.

Running the Batak Racers Software

- Turn on your PC..
- Install the gaming software on the supplied CDROM.
- Change your 'screen resolution' to: **800 by 600 pixels**
- **Double Left click** on the 'Batak Racers' application icon.
- Wait approximately 5 seconds for the gaming software to load.

What is Batak Racers?

Batak Racers is an interactive game for 2 – 6 players. The object of the game is to reach the finish line first. The faster you strike out your target lights then the quicker your car will go (represented by an on-screen marker).

How To Start the Game

When the game has loaded the following screen will appear...



To begin the game you should **left click once** using your wireless pointer/mouse **OR** press a key.

After the race has ended the appropriate winner's screen will appear.

To return to the introductory screen (as shown above) you should **left click once** using your wireless pointer/mouse **OR** press a key.

Batak Racers v1.0

SOFTWARE GUIDE

How To Stop a Race and Return to the Introductory Screen

At any time you can **return** to the introductory screen (as shown above) by pressing the **Escape** key (this is the **top left** key on the keyboard marked as **Esc**)

How To Quit the Game

At any time you can **quit** the game by pressing the **Q** key (pressing the lowercase **q** key will also work).

Shutting down Windows

You can shut down **Windows** by doing the following:

- Left click once on the **Windows Start** button
- Left click once on the **Shut Down** option
- Make sure that the '**Shut down**' option is selected on the 'drop down' options box
- Left click once on the **OK** button
- **Windows** will then shut itself down, please wait 20 seconds before proceeding.
- After 20 seconds it's safe to disconnect the power and other cables etc.